

CARE & MAINTENANCE

Concrete Surfaces

For indoor products (countertops, benches, fireplace surrounds & hearths) and outdoor products (barbecue tops, benches and furniture)

SEALER

Your concrete surface is treated with a quality sealer that provides maximum protection against water, oils, and acids. The sealer is freshly applied following installation of product and requires a few weeks to achieve full protection. After this, care must still be taken to maintain your concrete surface.

CARE

- Keep surface clean; wipe with damp microfibre cloth after use.
- Wipe up spills when they occur.
- Use only mild soap and warm water.
- Use a cutting board for food preparation.
- Use coasters or trivets for pots, pans or other heavy objects.
- Cover outdoor concrete surfaces with a tarp or similar material during winter months to protect from snow and/or ice.

CAUTION

- Do not clean using any abrasives or chemicals.
- Chips may occur if struck with another hard object and are not easily repaired.
- Acids, vinegar, or fruit juices may leave a light stain.
- Oils may leave a dark stain that will fade over time.
- Sliding heavy or sharp objects across the surface can cause scratches and damage to the sealer.
- Do not cut or use sharp instruments directly on the surface.
- Do not sit or stand on the surface, especially in vulnerable areas such as near the sink or an overhang.
- Other sealers may not be compatible with the original sealer.

MAINTENANCE

The appearance of your surface will likely change over time, due to wear and tear through normal use. The sealer may wear over time so, if the surface is no longer repelling as normal, please inquire about services to reseal your surface.

Should you have any questions or need our services, please call us at +1 855-711-5142 or email us at info@anthonyconcretedesign.com.

Thank you for choosing Anthony Concrete Design!